




# **Perfect for Many Applications**


### FLEXIBLE, SPACE AGE JACKING CAPABILITIES


- Highly flexible and lightweight jacks only require an air supply of 8 bar (116 psi) maximum. Water or non-explosive gas can also be used for inflation.
- Un-inflated jacks are less than 30 mm (1.2 in) thick, making lifting tasks in small spaces
- Constructed of non-conducting, high quality rubber material with multi-layer aramid fiber reinforcement.
- Samples of jacks are pressure tested to 20 bar and cycle tested (10,000 inflate / deflate cycles at 8 bar for 10,000 inflate / deflate cycles).
- The controller, shut-off and air hoses are all equipped with an industrial interchange style quick disconnect air coupler. Female half coupler bodies have a locking collar to help the operator avoid accidentally disconnecting the jack while under load.
- The top and bottom surface of the jack has a skid resistant, interlocking pattern to assist in alignment of two jacks being used together.
- Single jack controller with "dead man" control (part number 350090) can be used individually or in multiples to regulate the number of jacks desired.
- Heavy attachment handles are provided on the two largest jacks for attachment of a rope or hook to help in positioning the jack.
- Inflation hose system is color-coded (red and blue) for easy recognition when using more than one iack.
- The jacks can be used at ambient temperatures of -20°C (-4°F) to +50°C (+122°F).





### **TYPICAL APPLICATIONS**
















#### **CONVERSION**

kN	LBS	KG	TONNES
1	225	102	0.1
5	1124	510	0.5
10	2248	1020	1.0
50	11241	5099	5.1
100	22481	10197	10.2
500	112405	50986	51.0
750	168807	76479	76.5





#### **ACCESSORIES**



No. **15235** – Connector 1/8" NPT male x 1/4" NPT female. Wt., 0.1 lb.

No. **250341** – Female quick coupler. 1/4" industrial x 3/8" I.D. hose.

No. **250342** – Male Quick coupler. 3/8" I.D. Hose.

No. **250343** – Female quick coupler. 1/4" industrial interchange x 1/8" NPT female. Wt., 0.1 lb.

No. **250353** – Male quick coupler. 1/4" industrial interchange x 1/8" NPT male. Wt., 0.1 lb.

No. **250682** – Female quick coupler. 1/4" industrial interchange x 1/4" NPT male. Wt., 0.1 lb.

No. **307159** – Pressure reducing valve. Allows use of bottled gases to operate jacks (works on CGA-580 Nitrogen/Argon/Helium bottles). Contains standard bottle fitting on inlet and 1/4" industrial interchange (female) outlet. Wt., 4 lbs.

No. **350090** – Air controller for single jack. Equipped with relief valve and pressure gauge.

No. **350207** – Shutoff hose with shut-off valve and pressure relief valve. Includes a female and male quick coupler.

No. **350208** – Air hose. Red, 30' long. Includes No. 250341 female and No. 250342 male quick coupler.

No. **350209** – Air hose. Same as 350208, except blue in color.

#### **ORDERING**

Lift Capa	•	Ma Lifting		Order Number	Air Volume	Water Volume			Product Weight	
(kN)	(lbs)	(mm)	(inch)		(liter)	(liter)	(mm)	(inch)	(kg)	(lbs)
10	2,248	80	3.1	IJ13T	3.3	0.7	150 x 150 x 22	6 x 6 x 0.87	0.6	1.3
32	7,194	130	5.1	IJ45T	16.2	1.8	228 x 228x 22	9 x 9 x 0.87	1.5	3.3
50	11,240	150	5.9	IJ66T	22.5	2.5	270 x 270 x 22	11 x 11 x 0.87	2	4.4
100	22,480	215	8.5	IJ119T	76.5	8.5	380 x 380 x 25	15 x 15 x 0.98	4	9
200	44,960	290	11.4	IJ2211T	189	21	508 x 508 x 25	20 x 20 x 0.98	7	15.5
320	71,930	380	15	IJ3615T	450	50	658 x 658 x 25	26 x 26 x 0.98	13	29
400	89,920	405	15.9	IJ4516T	558	62	708 x 708 x 25	28 x 28 x 0.98	15	33
670	150,610	520	20.5	IJ7520T	1,206	134	908 x 908 x 25	36 x 36 x 0.98	24	53

<sup>\*</sup>See current price list for shipping weights.

## **CUSTOMER SERVICE CENTERS**

World Headquarters The Americas Customer Service Center	European Customer Service Center	Asia Pacific Customer Service Center	China Customer Service Center
5885 11th Street Rockford, Illinois 61109 USA Tel: 815.874.5556	Albert Thijsstraat 12 6471 WX Eygelshoven The Netherlands	7 Gul Circle Singapore 629563 Singapore	No. 1568 Hua Shan Road Treasury Building 11th Floor Shanghai 200052, China
Customer Service Tel: 800.541.1418 Fax: 800.288.7031	Customer Service Tel: 31 (45) 5678877 Fax: 31 (45) 5678878 infoeurope@powerteam.com	Customer Service Tel: (65) 6265 3343 Fax: (65) 6265 6646 infoasia@powerteam.com	Customer Service Tel: 86 (21) 2208.5888 Fax: 86 (21) 2208.5682 infochina@powerteam.com
Technical Services Tel: 800.477.8326			

info@powerteam.com

<sup>\*</sup> NOTE: 350090 air controller may be used individually to control one jack (see single line system), or in multiples to control additional jacks (see dual line system).