



SPX Hydraulic Technologies 5885 11th Street Rockford, IL 61109-3699 USA


powerteam.com


Tech. Services: (800) 477-8326 Fax: (800) 765-8326

Order Entry: (800) 541-1418 Fax: (800) 288-7031 **Parts List for:**

PE460A-50-220 PE460A-ABC


ELECTRIC HYDRAULIC PUMP





Item	Part	No.	
No.	No.	Req'd	Description
1	10022	4	Hex. Soc. Hd. Cap Screw (1-1/4-20 x 1-1/2 Lg.)
2	10909	1	Plug Fitting (3/8 NPTF)
3	201747	1	Decal (Pressure)
4	45911	1	Manifold
5	10177	10	Machine Screw (1/4-20 UNC x 3/4 Lg.)
6	203146	1	T-handle
7	10394	1	Hex. Nut (5/8-18 UNF)
8	47409	1	Reservoir Gasket
9	10050	4	Cap Screw (3/8-16 UNC x 1" Lg.; Torque to 90/100 in. lbs.)
10	214097	1	Key
11	40063OR9	1	Reservoir
12	309219	2	Trade Name Decal
13	307425	1	Motor Base Gasket
14	13273	1	Plug Fitting (3/8 NPTF)
15	10479	2	Plug Fitting (1/4 NPTF)
16	213674	1	Shaft Seal V-ring
17	53104	1	Electric Motor

HYDRAULIC SCHEMATIC




Refer to any operating instructions included with the product for detailed information about operation, testing, disassembly, reassembly, and preventive maintenance.

Items found in this parts list have been carefully tested and selected. **Therefore: Use only genuine Power Team replacement parts!**

Additional questions can be directed to our Technical Services Departments.

BASIC PUMP ASSEMBLY



ф

36


Rev. 2 Date: 28 May 2012

2 of 5

Sheet No.

Item	Part	No.		
No.	No.	Req'd	Description	
1	10267	1	O-ring (7/16 x 5/16 x 1/16)	
2	52883	1	Pump Body	
3	16320	1	Compression Spring	
4	10375	1	Steel Ball (1/4 dia.)	
5	23547	1	Top Plate Bearing	
6	11814	1	Ball Bearing	
7	23548	1	Top Plate	
8	15431	1	Needle Thrust Bearing	
9	15432	1	Needle Thrust Race Bearing	
10	35271	1	Angle Plate	
11	11228	1	Needle Thrust Bearing	
12	11227	2	Needle Thrust Race Bearing	
13	213706	1	Filler Cap	
14	11084	1	Pipe Plug (1/16 NPTF; Torque to 35/45 in. lbs. oiled)	
15	15695	1	Ball Bearing	
16	15693	1	Gerotor Set	
17	307296	1	Wear Plate	
18	213709	1	Seal Washer (Turn on - Do not push on)	
19	10390	1	Hex. Jam Nut (1/2-20 UNF)	
20	213686	1	Intake Tube	
21	10268	1	O-ring (1/2 x 3/8 x 1/16)	
22	11863	1	Backup Washer (PTFE)	
23	21484	1	Washer	
24	214882	1	Valve Connector (NOTE: Torque valve connector (#24) to 20/30 ft. lbs. into cover plate (#34). Hold valve connector and torque tube nut (#26) to 40/50 ft. lbs.)	
25	10430	1	Sleeve Tube (For 3/8 tube)	
26	10431	1	Tube Nut (5/8-18 UNF)	
27	308614	1	Tube (oil line)	
28	12696	1	Straight Fitting	
29	215033	1	Tee Fitting	
30	24730	1	Elbow Fitting	
31	15642	5	Soc. Hd. Cap Screw (1/4-20 UNC x 5" Lg.; Torque to 55/65 in. lbs.)	
32	214720	1	Spacer	
33	11421	1	Straight Nipple Fitting	
34	61566BK2	1	Reservoir Cover	
35	29682	1	Filter Strainer	
36	36925	1	High Pressure Pump Assembly (See sheet 3 of 5)	
37	21278	1	Relief Valve (Set at 10,100/10,700 PSI)	


HIGH PRESSURE PUMP ASSEMBLY -- AUTOMATIC VALVE LOW SPEED



Item	Part	No.		
No.	No.	Req'd	Description	
1	*16747	7	Torx Drive Cap Screw (1/4-28 x 1-3/4 Lg.; See diagram below)	
2	*36911	1	Pump End Plate	
3	*24549	4	Valve Guide	
4	*10445	4	Compression Spring (5/32 O.D. x 3/4 Lg.)	
5	*12223	4	Steel Ball (3/16 dia.)	
6	*20775	2	Piston	
7	*41006	1	Pump Barrel	
8	*41007	1	Valve Head	
9	200797	1	Adjusting Screw	
10	10386	1	Jam Nut (3/8-24 UNF)	
11	15691	1	Compression Spring (1/4 O.D. x 5/8 Lg.)	
12	200796	1	Spring & Ball Adapter	
13	10375	2	Steel Ball (1/4 dia.)	
14	201998	1	Sleeve	
15	12571	1	Roll Pin (1/8 dia. x 1-3/8 Lg.)	
16	15129	1	Compression Spring (3/16 O.D. x 7/8 Lg.)	
17	12042	1	Copper Washer (9/16 x 3/8 x 1/32)	
18	29690	1	Cap Screw (Torque to 180 in. lbs.)	
19	10442	1	Copper Washer (3/8 x 1/4 x 1/32)	
20	201995	1	Cap Screw (Torque to 80/90 in. lbs.)	
21	10419	1	Steel Ball (5/32 dia.)	
22	16465	1	Compression Spring (5/8 O.D. x 3/4 Lg.)	
23	202088	1	Piston	
24	308613	1	Valve Cylinder	
25	214941	3	Machine Screw (1/4-20 x 1-1/2 Lg.)	
26	10264	1	O-ring (1/4 x 1/8 x 1/16)	
27	10427	1	Pipe Plug (1/8 NPTF)	


Consult the factory when replacing items marked with an asterisk (*).

BOLT TIGHTENING SEQUENCE



NOTE: Assemble in sequence shown. Lubricate under head and on threads. Torque to 170 in. lbs.

MOTOR CONTROL ASSEMBLY



(For PE460A-50-220)

Sheet No. 4 of 5

Rev. 2 Date: 28 May 2012


Parts List, Form No. 100825, Back sheet 4 of 5

Item	Part	No.	
No.	No.	Req'd	Description
1	17782	1	Snap Button
2	10197	2	Hex. Nut (#10-24 UNC)
3	11108	3	Lockwasher (#10 External Tooth)
4	11856	1	Machine Screw (#10-24 x 1" Lg.)
5	11539	2	Machine Screw (#10-24 x 1/4 Lg.)
6	14812	4	Screw (#8-18 x 3/8 Lg.)
7	420718-4	1	Contactor
8	43126GY5	1	Control Box Cover
9	210112	1	Strain Relief Bushing
10	308752	8.5 ft.	Cord (14/3 SJTO)
11	15993	1	Strain Relief Bushing
12	305665	1	Transformer
13	25017	1	Remote Control Hand Switch (See Form No. 101644)
14	13532	1	Self-tapping Screw (#8-32 x 3/8 Lg.)
15	206857	1	Washer
16	51218GY5	1	Control Box Body
17	206962	1	Fuse (3A)
18	16887	1	Fuseholder
19	11202	1	Connector
20	212434	1	Washer
21	11539	2	Machine Screw (#10-24 UNC X 1/4 Lg.)

PARTS INCLUDED BUT NOT SHOWN

Warning Decal 200188

ELECTRICAL SCHEMATIC (For PE460A-50-220)





work must be done by a qualified electrician.

North American & International Color Codes:

Conductors	North American	International
Line	Black	.Brown
Neutral	White	.Blue
Ground	Green	.Green/Yellow

NOTE:

L3

UNLESS OTHERWISE SPECIFIED ALL UNITS ARE TO BE WIRED FOR 220 V.-50 HZ. (CCW ROTATION FROM LEAD END)

TRANSFORMER CONNECTIONS ARE AS SHOWN FOR 220 V.- 50 HZ.


FOR 110 V.- 50 HZ. UNITS, TRANSFORMER CONNECTIONS TO BE AS FOLLOWS:

> H1 & H3 TO L1 H2 & H4 TO L2

110/220 V., 50 Hz., Single Phase


Note: Shaded areas reflect last revision(s) made to this form.

MOTOR CONTROL ASSEMBLY (For PE460A-ABC)



Item	Part	No.	
No.	No.	Req'd	Description
1	309019	1	Pushbutton Switch
2	17782	1 Snap Plug	
3	10197	2 Hex Nut (10-24)	
4	11108	3 Washer	
5	11856	1	Screw (10-24 x 1" Lg.)
6	43126WH2	1	Control Box Cover
7	14812	4	Screw (8-18 x 3/8 Lg.)
8	51218WH2	1	Electrical Control Box
9	420718-4	1 Contactor	
10	11539	4 Screw (10-24 x 1/4 Lg.)	
11	205189	1	Ground Decal
12	15933	1	Strain Relief Bushing
13	12908	3 ft.	Cable (18/3 SJTO)
14	210112	1	Strain Relief Bushing
15	307440	1	Cord Set (8' lg.; 115 V.; 12/3 SJTO)
16	52203	1	Pressure Control
17	215857	1	Strain Relief Bushing
18	13532	1	Screw (8-32 x 1/2 Lg.)
19	206857	1	Special Washer
20	305665	1	Transformer
21	250442	1	Fuse (1.25 AMP, 250 V.)
22	16887	1	Fuse Holder
23	11202	1	Nipple
24	212434	1	Plain Washer
25	250440	1	Fuse Holder

ELECTRICAL SCHEMATIC (For PE460A-ABC) 110/220 V., 50 Hz., Single Phase





To help avoid personal injury, all electrical work must be done by a qualified electrician.

North American & International Color Codes:

Conductors	North American	International
Line	Black	.Brown
Neutral	White	.Blue
Ground	Green	.Green/Yellow

NOTE:

L3

UNLESS OTHERWISE SPECIFIED ALL UNITS ARE TO BE WIRED FOR 220 V.-50 HZ. (CCW ROTATION FROM LEAD END)

TRANSFORMER CONNECTIONS ARE AS SHOWN FOR 220 V.- 50 HZ.

FOR 110 V.- 50 HZ. UNITS, TRANSFORMER CONNECTIONS TO BE AS FOLLOWS:

H1 & H3 TO L1 H2 & H4 TO L2

Note: This page added at last revision to this form.