


SPX Corporation 5885 11th Street Rockford, IL 61109-3699 USA Tech. Services: (800) 477-8326 Fax: (800) 765-8326 Order Entry: (800) 541-1418 Fax: (800) 288-7031

Internet Address: http://www.powerteam.com

## **Parts List for:**

9581




Item	Part	No.	Deceriation
No.	No.	Req'd	Description
1	205956	1	Straight Fitting (Discard O-ring)
2	*10263	1	Copper Washer
3	21864	1	Valve Piston
4	12390	2	Backup Washer (5/8 x 1/2 x 1/16)
5	*10301	1	O-ring (5/8 x 1/2 x 1/16 CS)
6	65465	1	Valve Body
7	*10261	1	Soft Copper Washer
8	205955	1	Straight Fitting (Discard O-ring)
9	20771	1	Poppet
10	*10425	1	Spring
11	11088	1	Internal Retaining Ring
12	10676	1	Straight Fitting (3/8 NPTF)
13	10479	1	Pipe Plug (1/4 NPTF)
14	11127	2	Plug

Part numbers marked with an asterisk (\*) are contained in Repair Kit No. 27345.

Sheet No.	1 of 1
Rev.	Date: 22 Jan. 1997


## **SPECIFICATIONS**

This valve is intended for use with double-acting cylinders in circuits employing 3-position, 4-way tandem or open center valves without posi-check. Leakage normally associated with this type of valve when in the neutral position is eliminated . . . allowing pressure to be maintained in the cylinder. This valve is ideal for clamping operations where leakage must be avoided in order to maintain clamping pressure . . also adaptable to special applications using other types of 4-way valves. A pressure switch and/or gauge may be attached if required.



## TYPICAL HYDRAULIC CIRCUITS

Double-acting cylinder with a remote mounted, pilot operated check valve. (Holds cylinder pressure when valve lever is in neutral position.)



Double-acting cyinder with remote control valve and a remote pilot operated check valve. (Holds cylinder pressure when valve lever is in neutral postion.)

