


SPX Corporation 5885 11th Street Rockford, IL 61109-3699 USA Tech. Services: (800) 477-8326 Fax: (800) 765-8326 Order Entry: (800) 541-1418 Fax: (800) 288-7031

Internet Address: http://www.powerteam.com

**Parts List for:** 

**PA50D Series** 

# MODEL G AIR HYDRAULIC PUMP



Two gal on reservoir

Sheet No. 1 of 4

Rev. 4 Date: 2 April 2001


Item	Part No.	No. Req'd	Description
110.	NO.	nequ	Description
1	52514	1	Manual Pump Mount Valve (For PA50D, PA50D-AUTOROBOT,
			PA50D-BID & PA50D-2; See Form #100661)
2	211060	6	Screw (9-15 X 1;Torque to 25/30 in. lbs.; For PA50D,
	050400	40	PA50D-AUTOROBOT, PA50D-BID)
_	252168	10	Screw (1/4-10 X 1; For PA50D-2)
3	61243	1	Reservoir (1 gal. plastic)
4	61165	1	Reservoir (2 gal. plastic)
4	305494		Instruction Decal (For PA50D-AUTOROBOT & PA50D-2)
5	*33853	1	Reservoir Gasket (For PA50D, PA50D-AUTOROBOT, PA50D-BID, PA50DE, PA50DN & PA50DV)
	*47409	1	Reservoir Gasket (For PA50D-2, PA50D2E, PA50D2N &
	47403	'	PA50D2V)
6	40063OR9	1	Reservoir (2 gal. metal; For PA6DM-2)
	41300WH2	1	Reservoir (2 gal. metal; For PA6DM & PA6DM-DE-STA-CO)
	64153OR9	1	Reservoir (2 gal. metal; For PA6DM-1)
7	*16684	1	O-ring (1.18 X 1.0; For PA50D, PA50D-AUTOROBOT, PA50DN &
	18874	1	PA50D2N)  Oring (1.10 V.1.0: For PA50DV & PA50D0V)
	17718	-	O-ring (1.18 X 1.0; For PA50DV & PA50D2V) O-ring (1.18 X 1.0; For PA50DE & PA50D2E)
	*12779	1	O-ring (.93 X .81; For PA50D-BID)
8	251689	1	Filler/Breather Cap
9	*10273	1	O-ring (.81 X .62; For all except PA50DE, PA50DV, PA50D2E &
J	10270	-	PA50D2V)
	18999	1	O-ring (.81 X .62; For PA50DV & PA50D2V)
	250157	1	O-ring (.81 X .62; For PA50DE & PA50D2E)
10	305496	1	Tradename Decal (For PA50D-BID)
	305496CE	1	Tradename Decal (For PA50D)
	213883	1	Tradename Decal (For PA50D-AUTOROBOT)
	309219	2	Tradename Decal (For PA50R2)
	309219CE	2	Tradename Decal (For PA50D-2)
11	251762		Warning Decal (For PA50D-BID)
12	350568	1	Instruction Decal (For PA50D-AUTOROBOT)
		PA	RTS INCLUDED BUT NOT SHOWN
	252168	4	Screw (1/4-10 X 1; For PA50D-2; For pump mounting purposes only.)
	10474	1	90° Elbow Fitting (3/8 NPTF; For PA50D-BID)
	12328	1	Straight Fitting (1/4 NPTF; For PA50D-BID)
	12546	1	Plastic Cap (For PA50D-BID)
	251319	1	Plug Fitting (1/4 PTF; For PA50D-BID)
		-	- 3 ( )

Part numbers marked with an asterisk (\*) are contained in a repair kit see sheet 4 of 4 for individual repair kit information.



Parts List Form No. 101955

#### **TOP & END VIEW**



Note: These views may not be exact representations of your pump due to the variation of pumps listed, but all parts have been accounted for and are in this parts list.


Itor	n Bort	No.	
Iter No.		Req'd	Description
140.	140.	nequ	Description
1	351134BK2	1	Foot Plate (For all except PA50D-BID)
2	251757	1	Decal (For all except PA50D-BID)
3	37199	1	Air Intake Manifold (For all except PA50D-BID)
	309246	1	Air Intake Manifold (For PA50D-BID)
4	421166BK2	1	Cover Plate (For all except PA50D2E, PA50D-2, PA50D2N & PA50D2V)
	58705BK2	1	Cover Plate (For PA50D-2, PA50D2E, PA50D2N & PA50D2V)
5	11151	6	Screw (10-24 UNC X 1-1/4 Lg.; Torque to 50/60 in. lbs.)
6	58695	1	Manifold (For PA50D, PA50D-AUTOROBOT, PA50DE, PA50DN & PA50DV)
	58691	1	Manifold (For PA50D-BID)
	58714	1	Manifold (For PA50D-2, PA50D2E, PA50D2N & PA50D2V)
7	64767	1	Pump Body
8	17428	4	Screw (1/4-20 X 3-1/2; Torque to 85/95 in. lbs., oiled; Note: cross torque in increments of 30 in. lbs.)
9	205724	1	Attention Decal (For PA50DV & PA50D2V)
	250328	1	Attention Decal (For PA50DE & PA50D2E)
		PA	RTS INCLUDED BUT NOT SHOWN
	10469	1	Straight Fitting (3/8 NPTF; For PA50D-2)
	10470	1	90° Elbow Fitting (3/8 NPTF; For PA50D-2)
	10672	1	Straight Fitting (1/4 NPTF; For PA50D-BID)
	11127	2	Plug Fitting (3/8 NPTF; For PA50D-2)

Part numbers marked with an asterisk (\*) are contained in a repair kit see sheet 4 of 4 for individual repair kit information.

Sheet No.	2 of 4
Rev. 4	Date: 2 April 2001

#### **BASIC PUMP ASSEMBLY**

This view covers these following pumps:



Parts List Form No. 101955

Item No.	Part No.	No. Req'd	Description	Item No.	Part No.	No. Req'd	Description
1	*29992 28387		Foam Tube Muffler	16	10002	1	Screw (1/4-20 X 3/8; Torque to 90/110 in. lbs.)
2 3	*28239		Gasket	17		_	Relief Valve (When ordering a
4	52390		Piston Body	• •			replacement relief valve refer to
5	*14265		Piston Ring (2.77 X 2.54)				stamped number on the outside of the
6	*251835		O-ring (2-1/2" X 2-5/16" X 3/32; For all except PA50DV, PA50DE, PA50D2E & PA50D2V)	18	421642	1	relief valve. See note below. Apply loctite 592 [Power Team #905516] or equiv. & torque to 150/170 in. lbs.)  Cylinder Blank (Torque to 90/100 ft.
	251865	2	O-ring (2.31 X 2.12; For PA50DV &	19	*10423		lbs., oiled)
		_	PA50D2V)			1	Ball (9/32 Dia.)
	251866	2	O-ring (2.31 X 2.12; For PA50DE &	20	*10261	1	Special Washer (.75 X .60)
7	*10272		PA50D2E) O-ring (.75 X .56; For all except PA50DV, PA50DE, PA50D2E & PA50D2V)	21	48010	1	Filter Adapter (Torque to 40/50 ft. lbs., oiled; For all except PA50D-2, PA50D2E, PA50D2N & PA50D2V; See sheet 4 of 4 for pumps with 2 gal. reservoirs.)
	18998	1	O-ring (.75 X .56; For PA50DV & PA50D2V)	22	214578	1	Filter (For all reservoir sizes except 2 gal. reservoirs built after June 1, 1998)
	250194	1	O-ring (.75 X .56; For PA50DE & PA50D2E)	23	214586	1	Retaining Ring (.63 X .015; For all reservoir sizes except 2 gal. reservoirs
8	21094	2	Bushing				built after June 1, 1998)
9	*11863	4	Backup Washer (.50 X .38)	24	*10263	1	Special Washer (1.0 X .77)
10	*10268	4	O-ring (.50 X .37; For all except PA50DV, PA50DE, PA50D2E & PA50D2V)	25	*351662	1	Retainer (See Detail; Note: See "INSTRUCTIONS FOR RETAINER REPLACEMENT" on back sheet 4 of 4.)
	19775	4	O-ring (.50 X .37; For PA50DV)	26	*12488	1	Backup Washer
	17716	4	O-ring (.50 X .37; For PA50DE &	27	*253095	1	U-cup
			PA50D2E)	28	*17429	2	Backup Washer (2.94 X 2.75)
	11439		O-ring (.50 X .37; For PA50D2V)	29	*13938	1	Spring (1.452 O.D. X 4.4)
11	16448		Spring (.31 O.D. X .81)	30	28400	1	Piston (7/16")
12	15024	1	Straight Fitting (1/4 NPTF; For	31	202613	1	Bumper
40	*4.0070	0	PA50DE, PA50DN & PA50DV)	32	211082	1	Spring Guide
13	*10276 *10276		O-ring (1.0 X .75; For PA50D-2 & PA50D2N) O-ring (1.0 X .75; For PA50D, PA50D-AUTOROBOT, PA50D-BID, PA50DN &	33	37434	1	Air Cylinder (Note: Locate groove on upper half (top) of pump with chamfered tube end towards rear head as shown.)
			PA50DS-AUTO)	34	*12692	1	Spring (3/16 O.D. X 1.70)
	19026	2	O-ring (1.0 X .75; For PA50D2V)	35	*211052	1	O-ring (.90 X .70; For all except
	19026	3	O-ring (1.0 X .75; For PA50DV)				PA50DE, PA50DV, PA50D2E &
	250188	2	O-ring (1.0 X .75; For PA50D2E)		050400		PA50D2V)
	250188	3	O-ring (1.0 X .75; For PA50DE)		250192	1	O-ring (.90 X .70; For PA50DV & PA50D2V)
14	*10442	1	Special Washer (.37 X .25; For PA50D-2, PA50D2E, PA50D2N &		250193	1	O-ring (.90 X .70; For PA50DE & PA50D2E)
	*10442	2	PA50D2V) Special Washer (.37 X .25; For	36	305475	1	Exhaust Valve Stem
	10442	۷	PA50D, PA50D-AUTOROBOT, PA50D-BID, PA50DE, PA50DN, PA50DS-AUTO & PA50DV)	37 38	*10241 211054	3 3	Lockwasher (.33 X .20) Screw (10-24 X 1/2; Torque to 50/55 in. lbs.)
15	10807	1	Screw (1/4-20 X 1/2; For PA50D,	39	33822	1	Piston End Plate Casting
			PA50D-AUTOROBOT, PA50D-BID,	40	*28183	1	Piston Poppet
			PA50DE, PA50DN, PA50DS-AUTO &	41	*205679	1	Spring (.49 O.D. X .92)
			PA50DV)				-Continued-

Part numbers marked with an asterisk (\*) are contained in a repair kit see sheet 4 of 4 for individual repair kit information.

#### NOTE:

Standard relief valves are set at 10,100/10,700 PSI.

Relief valves pre-set at special settings are available.

Refer to your pump model number or contact Power Team Technical Services.

Note: Shaded areas reflect last revision(s) made to this form.

-Continued-





Sheet No. 3 of 4


Rev. 4 Date: 2 April 2001

## Parts List, Form No. 101955, Back sheet 3 of 4

Item No.	Part No.	No. Req'd	Description	Item No.	Part No.	No. Req'd	Description
42	*205674	1	Screw (8-32 X 3/8; Torque to 12/18 in. lbs.)		18974	1	O-ring (.43 X .31; For PA50DV & PA50D2V)
43	51480	1	Rear Head		13472	1	O-ring (.43 X .31; For PA50DE &
44	*251717	1	O-ring (1.0 X .62; For all except				PA50D2E)
			PA50DE, PA50DV, PA50D2E & PA50D2V)	53	33841	1	Actuator Button (For all except PA50D-BID)
	251718	1	O-ring (1.0 X .62; For PA50DV &	54	*11841	1	O-ring (1.62 x 1.37 Nitrile)
	054540		PA50D2V)		251695	1	O-ring (1.62 x 1.37 EPR)
	251719	1	O-ring (1.0 X .62; For PA50DE & PA50D2E)		19035	1	O-ring (1.62 x 1.37 Viton)
45	*351021	1	Coverplate Gasket		PARTS	INCLU	DED BUT NOT SHOWN
46	*216296	1	Filter Disc (For all except PA50D-BID)		10427	1	Plug Fitting (1/8 NPTF; For PA50D-
47	14794	1	Plastic Cap (For all except PA50D-BID)			'	AUTOROBOT)
48	12691	1	Spring (.36 O.D. X 1.50; For all except PA50D-BID)		15426	1	Straight Fitting (1/4 NPTF; For PA50D-AUTOROBOT)
49	13936	1	Screw (8-32 X 1/4; For all except PA50D-BID)				with an asterisk (*) are contained
50	28198	1	Seal Guide (For all except PA50D-BID)	III a	теран ки з		et 4 of 4 for individual repair kit formation.
51	*28182	1	Air Valve Poppet (For all except PA50D-BID)				
52	*10267	1	O-ring (.43 X .31; For all except PA50D-BID, PA50DV, PA50DE, PA50D2E & PA50D2V)				



### **DETAIL "A-3"**




Item No.	Part No.	No. Req'd	Description
1	36497	1	Check Valve Retainer
2	*211053	1	O-ring (.37 X .25; For all except PA50DE, PA50DV, PA50D2E & PA50D2V)
	11438	1	O-ring (.37 X .25; For PA50DV & PA50D2V)
	17715	1	O-ring (.37 X .25; For PA50DE & PA50D2E)
3	*10445	1	Spring (.16 O.D. X .72)
4	202568	1	Ball Guide
5	*10423	1	Ball (9/32")

Part numbers marked with an asterisk (\*) are contained in a repair kit see sheet 4 of 4 for individual repair kit information.

Parts List Form No. 101955

#### FILTER ADAPTER ASSEMBLY BEFORE 6/1/98

For 2 Gallon Reservoirs Only




Item No.	Part No.	No. Req'd	Description
1	*10423	1	Ball (9/32 Dia.)
2	*10261	1	Special Washer (3/4 x 19/32 x 1/32)
3	48008	1	Filter Adapter (Torque to 40/50 ft. lbs., oiled; For PA50D-2, PA50D2E, PA50D2N & PA50D2V)
4	214578	1	Filter
5	214586	1	Retaining Ring (.63 x .015)

Part numbers marked with an asterisk (\*) are contained in a Repair Kit see sheet 4 of 4 for individual repair kit information.

#### **FILTER ADAPTER ASSEMBLY AFTER 6/1/98**

For 2 Gallon Reservoirs Only (Reference Part Number 48008)



Item	Part	No.	Description
No.	No.	Req'd	
1	422017		Filter Adapter
2	29682		Filter

#### **REPAIR KITS**

No. 300962 PA50D PA50DN No. 300961 PA50D-2 PA50D2N No. 300963 PA50D-AUTOROBOT PA50D-BID

Sheet No.	4 of 4
Rev. 4	Date: 2 April 2001

#### INSTRUCTIONS FOR RETAINER REPLACEMENT

Your pump's retainer is locked into place by one of the two following methods. Determine which <u>method</u> was used on your pump's retainer, then follow the appropriate steps to remove the old and install and stake the new.

#### Method 1 - Retainer shows no sign of stake marks

- 1. This retainer has been locked in place with a Loctite product. To replace it, a moderate amount of heat needs to be applied to the cylinder nut (in the area of the retainer) to soften the existing Loctite allowing it to be removed.
- 2. Install the new retainer into the cylinder nut and torque to 80/100 in. lbs. Note: Do not use a Loctite product this time but stake the new retainer in place according to instructions in Step 3.
- 3. To lock retainer into place, use a center punch positioned in the seam between the retainer and the cylinder nut and stake the new retainer in two places approximately 180° apart.

# Method 2 - Retainer has two stake marks in the seam between the retainer and the cylinder nut

- 1. For replacement of this retainer, the stake marks must be removed. Using a 1/8" or larger diameter drill bit, remove the existing stakes by drilling a short distance into the stake marks. Remove the retainer.
- 2. Install the new retainer into the cylinder nut and torque to 80/100 in. lbs.
- 3. To lock retainer into place, use a center punch positioned in the seam between the retainer and the cylinder nut and stake the new retainer in two places approximately 180° apart.

NOTE: Do not stake in the old stake marks.

