## **>Power Team**<sup>•</sup>



### **MOTION CONTROL SYSTEM**



PRECISE POSITIONING & CONTROL IN A RESPONSIVE PACKAGE

## SPXFLOU



#### **Motion Control System**

The new Power Team Motion Control System (MCS) can be used in many hydraulic applications where load position is critical, requiring cylinder synchronization.

Whether it is a bridge, a building or any kind of heavy load, with the SPX FLOW Power Team Motion Control System, lifting, lowering, pushing, pulling, tilting or positioning loads can be carried out automatically with a high degree of accuracy.

MCS Value Delivered:

- PLC controlled system provides significant time saving advantages coupled with precise accuracy
- Extremely low internal stress in the object one is moving reduces the risk of costly damage to the load
- Data is captured & documented for the movement performed

#### Magnetic Mount Sensors







#### Key Features

- HMI touch screen provides great visibility and easy access to system controls.
- 2 Hinged cover provides protection for HMI and doubles as a sun screen.
- State of the art digital PLC control provides easy access to the system & log data.
- Pressure sensors to monitor lifting pressures in each circuit.
- Electrically controlled valves to control the distribution of oil into the hydraulic circuits in small increments.
- Forty (40) gallon (150 Liters) reservoir with sight gauge to handle a wide range of cylinder combinations.
- Heavy-duty frame designed to handle all industrial applications.
- Integrated lift points for cranes and forks.
- Feedback sensors to monitor the position of the load up to 19.7 in (500 mm). Optional length 40 in (1 m) is available upon request.



#### Data Log/Report Captured



The Main Benefit of a Motion Control System (MCS)

ERIES

The Power Team MCS digitally controls the movement of an object, keeping it level within the user specified parameters. The primary reason to use a Power Team MCS is Internal Stress Reduction. When a large object is stationary, internal stresses are normalized. When the object is moved, stresses are induced. If the operator is not careful, the object can bend or twist creating a stress riser that can cause costly repairs or damage. The MCS system will assist in controlled positioning to manage the stresses created by synchronously lifting or

#### Easy to Use HMI Touch Screen Interface

lowering the object in unison.

Features	Benefits
Control of lifting, positioning or lowering loads from PLC	Safe and accurate movement of loads
State of the art software in the PLC	Enables accuracies as low as 1 mm (0.040 in)
NEMA 12 electrical box rating	Able to operate in wide range of temperature (32 –131°F, 0 – 55°C) and humidity (30 – 95% non-condensing)
Multiple safety features and auto diag- nostics	Full stop due to power failure, sensor failure, pressure overload, tolerance error, uncon- trolled load movement.
Data log card	Data recording and reporting capabilities



The home screen on the Motion Control System is easy to use and operate. It highlights all activities during use of the Motion Control System. For each cylinder in operation, the cylinders performance is captured and displayed on the HMI screen as illustrated below.



#### Safety Features

The Power Team Motion Control System (MCS) has numerous safety features built into the digital controller which safely stop the movement in the event of an alarm. In addition, there are backup mechanical features which function even in the event of a power loss.

Digitally Controlled Safety Features		Mechanical Backup Safety Features		
Max load exceeded	Hydraulic pump overload			
Max pressure exceeded	E-Stop button activation	Posi-Check <sup>®</sup> load lowering valve to hold load and provide a mechanical backup to safely control the		
Max displacement exceeded	Pressure sensor wire break	lowering of the load.		
Datalog error	Displacement sensor wire break	Manual lowering override to safely		
System communication error	Two button start procedure prevents accidental starting	lower load in event of power loss.		

#### Common applications include:

- Bridge lifting, repositioning, maintenance & launching.
- Controlled movement and positioning of heavy equipment, buildings, concrete segments and other construction components.
- Structural testing in civil engineering.
- Lifting, weighing and/or determining center of gravity.
- Structure raising, leveling & shoring.



Pictured above: rudder installation for routine maintenance in a dry dock application. Below: Positioning of HVAC equipment during installation.



#### **8 POINT MOTION CONTROL SYSTEM**

#### >Power Team



#### Order No.: MCS-PE554-8



#### Features

- Basic systems includes eight (8) jacking points, contact Power Team for larger MCS system requirements.
- Positioning, lifting or lowering accuracy of +/- 1 mm (0.040 in).
- Safety features included: full stop due to power failure, sensor failure, pressure overload, tolerance error, uncontrolled load movement, etc.
- Intuitive graphic, touch screen control
- Displayed information included: startup diagnostics, position of lift points relative to starting position, pressure at each lift point, status of each cylinder and status of alarms.
- MCS works with a wide range of cylinders types, tonnages and strokes to meet your application requirements.
- Operating pressure (up to) 10,000 psi (700 bar).
- Standard system has a 40 gallon (150 liters) gallon tank.



#### **Touch Screen Enclosure**

- Weather tight enclosure protects your investment while in storage.
- Hinged cover provides protection for HMI touch screen.
  - Designed to act as a sun screen in bright conditions.



#### **Cylinder Selection**

Always choose a cylinder with a tonnage rating of 20% or more than what is required to lift or position the load.

Power Team supplied the lift equipment expertise for this drag line maintenance operation to successfully complete the job on time.



#### **8 POINT MOTION CONTROL SYSTEM**

#### Technical Dimensions



#### Hardware Included



Motion Control System (MCS) is protected with a robust cage and reusable shipping container.

#### Ordering Information



Linear Displacement Sensors have a range of 19.7 in (500 mm). Two cases with four sensors included. Refer to the ordering table for the 39.4 in (1000 mm) ordering option.



#### **Training Provided**

Every MCS includes one day of on-site training at one of SPX FLOW's Regional Headquarters (Rockford, IL USA or Singapore or the Netherlands).

Training includes both classroom and hands-on instruction. Travel & lodging not included.



#### **Optional Cylinders**

Power Team offers a wide variety of single, double, lock nut, pancake and center hole cylinders to meet your requirements.





Cables for sensors are 100 ft (30.5 m) in length, eight sets and a hard plastic case.



Electrical plug female connector allows for quick attachment to your line cord.

Order No.	Max Lift Points	Pump Flow @	Reservoir Size	Motor Voltage	Max Pressure	Valves Included	Transducers Included	Weight w/oil
		10,000 psi (700 bar)	gal (L)		psi (bar)			lb (kg)
MCS-PE554-8	8	55 in³/min (0.9 L/min)		1.125hp (230V,1Ø)	10,000 (700)	3P-4W & 2P-2W	Pressure & Linear Position (500 mm)	1700 (771)
MCS-PQ1204-8		120 in <sup>3</sup> /min (1.97 L/ min)	40 (150)	3hp (230V, 3Ø, 60 Hz)				
MCS-PQ1204-460-8				3hp (460V, 3Ø, 60 Hz)				1715 (780)
MCS-PQ1204-50-220-8				3hp (220V, 3Ø, 50 Hz)				
MCS-PQ1204-50-380-8				3hp (380V, 3Ø, 50 Hz)				

Note: To upgrade to a 1000 mm linear position sensor, add "-1M" to the end of the part number. Example MCS-PE554-8-1M.

#### **CUSTOMER SERVICE CENTERS**

#### **North America**

5885 11th Street Rockford, IL 61109 USA

Customer Service/Order Entry Tel: +1 800 541 1418 Fax: +1 800 288 7031

**Technical Services** Tel: +1 800 477 8326 Fax: +1 800 765 8326 info@powerteam.com

#### **European Headquarters**

Albert Thijsstraat 12 6471 WX Eygelshoven The Netherlands Tel: +31 45 567 8877 Fax: +31 45 567 8878

infoeurope@powerteam.com

#### Asia Pacific Headquarters

26 Soon Lee Road Singapore 628086 Singapore Tel: +65 6265 3343 Fax: +65 6265 6646

infoasia@powerteam.com

#### Shanghai, China

No. 1568 Hua Shan Road Treasury Building 11th Floor Shanghai 200052, China Tel: +86 21 2208 5888 Fax: +86 21 2208 5682

infochina@powerteam.com

#### Visit us at www.powerteam.com





# **Distributed by:** SPXFLOU

Specifications subject to change without notice

PTMCS\_1509\_EN

#### **ENGINEERING, MANUFACTURING** AND SUPPORT CENTER

#### **World Headquarters**

5885 11th Street Rockford, IL 61109, USA Tel: +1 815 874 5556 Fax: +1 800 288 7031

info@powerteam.com