## **BOTTLE JACKS**

## Telescoping 6-15 Ton

THESE JACKS OFFER GREATER EXTENDED LIFTING CAPABILITY.





 Telescoping jacks offer all of the quality features and capabilities of the standard bottle jack line with a bonus. The super-long stroke of these jacks saves time and effort by eliminating the need to lift, crib, lift, etc. In most applications, the user can place the jack once and complete the lift.

 The taller 9006X, 9011X and 9013X all feature a unique beveled base that allows the jack to "follow" the load laterally as it is raised, greatly reducing side-loading of the piston.

| ORDERING INFORMATION* |    |        |       |                                |                 |                                       |                   |                                   |                                 |                                   |        |                   |
|-----------------------|----|--------|-------|--------------------------------|-----------------|---------------------------------------|-------------------|-----------------------------------|---------------------------------|-----------------------------------|--------|-------------------|
| Order                 |    | Stroke |       | Ext.                           | w/Screw<br>Ext. | No. Pump<br>Strokes to<br>Ext. Piston | Dia.              | Base                              |                                 | Handle<br>Effort at<br>Rated Cap. | Carry  | Product<br>Weight |
| Number                |    |        | (in.) | (in.)                          | (in.)           | (in.)                                 | (in.)             | (in.)                             | (in.)                           | (lbs.)                            | Handle | (lbs.)            |
| 9006X                 | 6  | 12     | 81/2  |                                | 201/2           | 14                                    | 13/4              | $4^{3}/_{4} \times 5^{1}/_{4}$    | 27 <sup>9</sup> / <sub>16</sub> | 79                                | No     | 14                |
| 9011X                 | 11 | 10.3   | 77/8  | 211/16                         | 207/8           | 25                                    | 1 <sup>5</sup> /8 | $6^{5}/_{16} \times 6^{1}/_{2}$   | 27 <sup>9</sup> / <sub>16</sub> | 88                                | No     | 19.5              |
| 9013X                 | 13 | 10     | 91/16 | 3 <sup>5</sup> / <sub>16</sub> | 227/16          | 35                                    | 1 7/8             | $6^{15}/_{16} \times 7^{5}/_{16}$ | 279/16                          | 79                                | Yes    | 25                |

<sup>\*</sup>See current price list for shipping weights.